

Mailbox Access No Message Waiting Light

Dial Voice Mail
Access Code
[]

Press [#]
Then Enter Your Mailbox Number

Enter Your Mailbox PassCode

Mailbox Access with Message Waiting Light

[MBOX] Key
Flashing

[MSG] Key
Flashing

Press [MSG] Key, Then [#]
to access your Mailbox

Enter Your Pass Code

M A I N U S E R M E N U

[*] New Messages

While Playing Messages:
[*] Scroll Back
[0] Pause
[#] Scroll Forward
[8] [1] Decrease Playback Speed
[8] [2] Increase Playback Speed
[8] [8] Increase Volume

[1] Message Folder

[2] Make Messages

[3] User Options

[4] System Management

[5] Change Out Call

[8] Exit Voice Mail

[9] System Greeting

Play Message
[1] Play New Messages
[2] Play Saved Messages
[3] Play Archived Messages
[4] Play Message Receipts
[5] Play Deleted Messages
[9] Exit Messages Folder

Record Message

[1] Mailbox Name
[2] Mailbox Greeting
[3] Change Pass Code
[4] Distribution Lists
[5] Block / Forward
[6] Setup Tutorial
[7] Time and Date
[8] Message Replay Order
[9] Exit to Previous Menu

[1] Open Mailbox
[2] Class of Service
[3] Delete Mailbox
[4] Remove Passcode
[5] System Time
[6] System Date
[7] Activate Holiday
[8] DTMF Activate / Deactivate
[9] Exit to Previous Menu
[*] Play Script Revision
[#] Clear BK Message

[1] Review Messages
[2] Discard Messages
[3] Save Message / Keep Message
[4] Forward Message
[5] Reply to Message
[6] Archive Message
[7] Skip Message (New Only)
[8] Message Information
[9] Exit to Previous Menu

[1] Review Message
[2] Discard Message
[3] Append Message
[4] Send Message to User
[5] Send Message to Distribution List
[9] Exit to Previous Menu

[1] Create List
[2] Add / Delete Mailboxes
[3] Play Distribution
[9] Exit to Previous Menu

[1] Regular User
[2] Administrator
[3] Mailbox Information
[4] Advanced User
[9] Exit to Previous Menu

[1] Select Schedule
[2] Cascade
[3] Edit
[9] Exit
[0] Deactivate

[1] Review Messages
[2] Discard Messages
[3] Keep Message in Archive
[4] Forward Message
[5] Reply to Message
[7] Move to Saved Folder
[8] Message Information
[9] Exit to Previous Menu

[1] Send Message
[2] Address Options
[9] Cancel

[1] Add Mailboxes
[2] Remove Mailboxes
[9] Exit to Previous Menu

[1] Play Time of Day
[2] Set Time of Day
[9] Exit to Previous Menu

[1] Play Date
[2] Set Date
[9] Set Day of the Week
[9] Exit to Previous Menu

[1] Activate
[2] Deactivate
[9] Exit to Previous Menu

[1] Review Message
[3] Skip Message
[6] Move to Archive Folder
[7] Move to Saved Folder
[8] Message Information
[9] Exit to Previous Menu

[1] Receipt Request
[2] Mark Private
[3] Mark Urgent
[4] Cancel
[9] Exit to Previous Menu

[1] Select Active Greeting
[2] Record Greeting
[3] Play Greeting
[4] Discard Greeting
[9] Exit to Previous Menu

[1] Play Time and Date Always
[2] Play Time and Date on Request
[9] Exit to Previous Menu

[1] Oldest
[2] Newest
[9] Exit to Previous Menu

[1] Create
[2] Modify
[3] Play
[9] Exit

Omega-Voice VMI Software Version 2.02 or Higher

[1] Play
[2] Block
[3] Forward
[4] Override
[9] Exit to Previous Menu

[1] Allow
[2] Disallow
[9] Exit to Previous Menu

[1] Disable
[2] Enable for Day
[3] Night
[4] Both
[9] Exit to Previous Menu

[1] Message Type
[2] Caller Type
[3] Method
[4] Time
[5] Number
[6] Pause Display
[7] Pager Display
[8] Attempts
[9] Interval
[*] Exit

